



# INVUE®


## J704 Alarming Showcase Base Unit and Cover




- 1 Decide how the power cable will be routed, either through a hole in the fixture, or out of the rear of the unit. If exiting from rear of unit, route cable through channel at back of box.



- 2 Insert power cable through one of the two available openings in the bottom of the box.




- 3 Plug barrel jack into barrel jack outlet on inside of unit. Twist barrel jack in the socket so that the cable is held in place.




## Stud Mount Only (Option A)

- 4A Drill two 19mm holes 150mm apart. From below unit, insert two mounting bolts as shown.




- 5A Thread power cable through one of the holes in the display surface. Slot bolts into holes and place unit on counter. From under counter, slide plastic security washer onto mounting bolt. Tighten metal wing nuts on mounting bolt.




**Go to step 8.**

## Adhesive Mount (Option B)

- 4B Wipe display counter with alcohol wipe provided. **Let dry completely.** Peel clear film from adhesives.




- 5B Place unit in desired location and press firmly to display surface for at least 10 seconds.




**Go to step 8.**

## Adhesive Mount with One Stud Mount (Option C)


- 4C** Drill one 19mm hole into display surface. Wipe display counter with alcohol wipe provided. **Let dry completely.**




- 5C** Insert one mounting bolt into center of base unit and peel clear film from adhesives. Thread the power cable through the hole in the display surface.



- 6C** Insert mounting bolt through hole and set unit on display surface. Press firmly for at least 10 seconds over adhesive feet.




- 7C** From under counter, slide plastic security washer onto mounting bolt. Tighten metal wing nuts on mounting bolt.




**Go to step 8.**

- 8** Plug power cable into power outlet. The LED will flash and a confirmation “beep” will sound, informing you that the base unit is receiving power.




- 9** Use InVue IR Key to give base unit store code. Press programmed IR key to IR lens on side of base unit and press the button on the IR Key. Flashing LED and a confirmation “beep” ensures programming has taken place.




If double “buzz” noise, an error has occurred, please try again.

- 10** For watch stem installation, see instruction sheet provided with stems.




- 11** Place angled end of trim cover under watch stems and press forward into the box. The angled end should be resting against the base of the stems. Place other end of trim cover so that it sits level with the top of the base unit.



12


Trim cover should now be positioned as shown below.

**Note: trim cover should not cover outside ring of box.**




13

Place cover over secure showcase base unit and insert edges into channel on outside ring of box.




14

When cover is on, base unit will “beep” and LED will stay lit. This confirms that the unit is secure.




## Arm/Disarm

Press programmed InVue IR Key to IR lens on side of base unit and press the button on the IR Key. Confirmation “beep” will sound to show unit is disarmed. If double “buzz” sounds, an error has occurred, please try again. To arm, place cover back into base unit and press down.




## Accessing Chargers or Re-merchandising

Insert InVue key FOB into slot in trim cover. Lift trim cover from base unit using key FOB and remove. When finished, replace trim cover as shown in steps 11 and 12.



## Caution

For proper operation of certain devices in Demo mode, the ambient temperature of the Secure Showcase should **not exceed 30° Celcius (86° Fahrenheit).**



## Fragile: Handle With Care



**For Cleaning: Clean using a dry microfiber cloth.**

SD0357 Rev2 10/3/16

# InVue

[www.invue.com](http://www.invue.com)

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.  
InVue is a registered trademark of InVue Security Products.