


# inVue

## Universal Lock Removal Tool

PL151



## OVERVIEW

Review entire instruction guide before starting installation.

### Components:

1. Universal Lock Removal Tool (PL151)

### Quick Start Overview:

1. Unlock cabinet and open panel doors
2. Remove Universal Lock
3. Remove Strike Plate


### System Overview:

Tool is used to remove Universal Lock and Strike Plate from cabinets.



### Caution:

Wear appropriate safety gear (gloves and eye protection) when working with and around glass cabinets.

**1****Unlock the Universal Lock with IR2 Key.**



\*IR2 Key must be charged and activated. See IR2 Key instruction guide.

**PRESS  
HERE**




**"BEEP"**

Note: If double "buzz," then an error has occurred. Ensure panels are fully closed and try again.


**2a****Open panels.****2b**

**Slide removal tool over Universal Lock. Move removal tool up or down along plane of glass panel to remove Universal Lock.**




**3**

*Access Strike Plate from inside cabinet. Pry strap away from panel manually or with edge of tool.*

**TOP VIEW****4**

*Return panels to closed position. Slide small end of removal tool around Strike Plate. Move removal tool up or down along plane of panel to remove Strike Plate.*





tough security made easy

**[www.invuesecurity.com](http://www.invuesecurity.com)**

**Corporate Office (North America) // 704.752.6513 • 888.55.INVUE**

**Europe, Middle East & Africa // +31.23.8900150**

**Asia Pacific // +852.3127.6811**

**Latin America // +52.55.9000.3957**