


inVUE

CT100

Premium Tablet Stand



Overview


Important! Read entire instruction guide before starting installation.

System Components

1. Tablet Stand (CT100)
2. Shroud
3. Power Connector
4. OEM Power Supply
5. IR Key (AF4400 or PK4400) – To unlock shroud from stand

System Overview:

The Premium Commercial Tablet Stand and Shroud are used to secure your tablet.



Power Connector



OEM Power Supply



Key
AF4400 or PK4400


TOOLS



Drill




Hole Saw
19 mm (0.75")




TT15 Bit

- 1** Drill a 19 mm (0.75") hole in display counter. Wipe display counter with alcohol wipe provided. **Let it dry completely.**




- 2** Plug power connector into merchandise.




3

Slide tablet into bottom shroud. Slide top of shroud to merchandise. Tighten **both screws** with TT15 bit.




4

Remove tab to activate battery. Remove both adhesive films on stand and slide cord and stand threaded post through hole. Press firmly for at least 10 seconds.




5

Slide security washer and metal washer onto stand below counter. Slide stand cord in opening of washer. **Loosely tighten washer.**





6


Snap shroud onto stand. You should hear a “beep.” Confirm shroud is fully engaged on all sides and is locked on stand by pulling on shroud.



- 7 Confirm shroud is aligned correctly and straight with front of display counter. **Fully tighten washer.**




- 8 Plug power supply to OEM and plug into outlet.




9

Rotate shroud 90 degrees to display in landscape.




Removing Shroud

Place IR key onto IR lens on stand. Press button on IR key to release shroud from stand. Stand will re-lock automatically after 5 seconds.



Removing Merchandise

Remove **both screws** with TT15 bit. Lift up on handle to slide shroud off and remove merchandise.



Frequently Asked Questions & Tips

- Q** My merchandise is not powering up.
- A** 1) Confirm correct power connector is being used for merchandise model. 2) Confirm power connector is completely plugged into merchandise (page 2). 3) Confirm power supply is plugged into stand cord and outlet (page 11).
- Q** Lock is not engaging.
- A** 1) Confirm power supply is plugged into stand cord and outlet (page 11).
- Q** My stand is loose or not stable.
- A** Confirm clear film on adhesive has been removed (page 7) and wingnut below counter is fully tightened (page 10).
- T** Once IR Key is used to remove shroud from stand, you have 10 seconds before stand re-locks (page 13).
- T** Confirm all sides of shroud are fully engaged with stand (page 9).
- T** Confirm correct power connector and shroud are being used for merchandise model.

inVUE®

tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE

Europe, Middle East & Africa // +31.23.8900150

Asia Pacific // +852.3127.6811

Latin America // +52.55.90003957