


inVue®

LTO III
Stylus Sensor
LTO1501




Read entire instruction guide before starting installation.

System Components


1. Stylus Sensor
2. Zip Tie
3. IR Key (*not included*)

System Overview

The LTO III Stylus Sensor protects all stylus pens and is only compatible with LTO1551.



Stylus Sensor
LTO1501




Zip Tie
(*included with sensor*)



InVue IR Key
AF4400 or PK4400


1

Wipe stylus pen with alcohol wipe provided. Let it dry completely.




2

Remove clear adhesive film from sensor. Press onto stylus pen for at least 10 seconds.




3

Tighten zip tie around stylus pen. Cut excess zip tie.



4

Plug sensor into LTO1551 fuse.





tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE

Europe, Middle East & Africa // +31.23.8900150

Asia Pacific // +852.3127.6811

Latin America // +52.55.9000.3957