



S1060

Sensor Removal Tool


DRG400




- 1 Unplug power connector from device.




- 2 Place removal tool into the appropriate holes provided on the sensor.



- 3 Insert removal bit of multitool into the removal tool.



- 4 Twist to remove sensor from the device.



SD0348 Rev0 04/28/16

inVue®

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811