



# inVue

## LT04



Replacement Stand Sled With PSA  
(SLD300)





- 1 Stand Installation:**  
If routing power cable through the fixture, drill a 19mm hole minimum (or 9mm slot minimum) in the fixture. Clean the surface of any debris.



- 2a With Breakaway Feature:**  
Determine if the breakaway feature will be used. If so, clean the fixture surface and the bottom of the breakaway plate with the provided alcohol wipe. Let dry completely.





- 3a** Remove the clear film from one side of the adhesive and apply to the bottom of the breakaway plate.




- 4a** Remove the clear film from the adhesive on the bottom of the breakaway plate. Press the plate to the table for at least 10 seconds.



**Note:** Be sure that the notch in the plate is towards the back and the plunger hole is over the fixture surface



- 5a Optional:**  
Drill pilot holes and install the 2 screws into the breakaway plate for additional security.




- 6a** If routing power cable across the surface of a fixture, route the power cable through the channel in the stand and out through the mouse hole on the back of the stand. Then snap the stand to the breakaway plate.




- 7a** If routing through a hole; Route the cable through the breakaway plate and the hole (or slot) in the fixture. Snap the stand to the breakaway plate.


**Note:** Force may be necessary to fit the stand onto the plate.




- 8a** **Note:** Be sure the plunger on the bottom of the stand presses against the top surface of the fixture.




- 2b** **Without Breakaway Feature:** If not using the breakaway feature and routing the power cable across the surface, route the power cable through the channel in the stand and out through the mouse hole on the back of the stand. Then snap the stand to the breakaway plate.
- Note:** Force may be necessary to fit the stand onto the plate.




- 3b** If routing the cable through the fixture, route the cable through the breakaway plate. Snap the stand to the breakaway plate.
- Note:** Force may be necessary to fit the stand onto the plate.




- 4b** Install the 4 provided screws to secure the plate to the stand.




- 5b** Clean the fixture surface and the breakaway plate with the provided alcohol wipe. Let it dry completely.




- 6b** Remove the clear film from one side of the adhesive and apply to the bottom of the breakaway plate.




- 7b** **Optional:** Install the optional stud kit (DGD403), by threading the stud into the stand.




- 8b** Remove the clear film from the adhesive on the bottom of the stand.




- 9b** Locate stand over the hole or at the desired location on the fixture. Orient the stand so that the coiled cable is facing away from the customer. Press stand against the surface for at least 10 seconds.




- 10b** **Note:** Be sure the plunger on the bottom of the stand presses against the top surface of the fixture.




- 11b** If optional stud kit is used, attach plate and nut onto the stud and tighten against the fixture.



**For All Mounting Methods:**  
Plug the power cable into the power supply (OEM or InVue). Plug power supply into power outlet.




To arm, use IR key.




# 1 Stand Removal:

To disarm, use the IR key.




# 2

If stud kit was used, unscrew stud mount from the stand.




# 3

If the breakaway feature was used remove the stand from the plate.



# 4

Remove the screws attaching the breakaway plate the the table (if used). Use the multitool scaper attachment (DNTX93) to break the adhesive bond between the plate and the fixture surface.



SD0453 Rev0 04/07/17

# inVue

[www.invue.com](http://www.invue.com)

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2017 InVue Security Products Inc. All rights reserved.  
InVue is a registered trademark of InVue Security Products.