





LT04


Handheld Medallion with Arms, Tablet Medallion with Arms, Tablet Medallion with Viper Arms (SLH200, SLT200, SLT201)




- 1 Sensor Installation:**
Clean the back of the merchandise with the provided alcohol wipe. Let it dry completely.




- 2** Use a philips head bit to loosen the plate. Slide the arms out.




- 3** Loosen the hands on the bracket arms with the T-20 bit.




- 4** Use T-20 bit to remove the screw holding the sensor to the merchandising plate.




- 5** Remove the merchandising plate from the sensor by turning it clockwise and pulling it away from the sensor.




- 6** Remove clear film from the adhesive on the security arm plate.




- 7a Optional:**
If using an LSE plate, align the slot on the plate with the slot on the security arm plate as shown below. Apply pressure for at least 10 seconds.




- 7b Remove the paper backing from the LSE plate.




- 8 Determine the mounting position of the merchandise on the stand.
Note: If mounting the stand to a table the hook on the plate should be on the left. If mounting to a wall the hook will be on the right.




- 9 Center the plate on the back of the merchandise and confirm that the arms will not interfere with buttons on the merchandise. Press firmly for at least 10 seconds.




- 10 Firmly press the security arms against the merchandise and tighten the screws on the plate to secure the arms.




- 11 Use the T-20 bit to tighten the hands against the merchandise. **Do not overtighten as this may damage the merchandise.**




- 12 Plug power connector into the sensor.




- 13 Hook the security arm plate into the sensor. Rotate the plate counter-clockwise to lock into place. **Use caution to not damage the device.**




- 14 Use T-20 bit to tighten sensor to the plate.




- 15 Plug power connector into merchandise.




- 16 Attach sensor to stand/puck.




- 17 To arm, use IR key.




- 1 **Sensor & Security Arm Removal:**
Disarm using the IR key.




- 2 Unplug the power connector from the merchandise.




- 3 Use T-20 bit to loosen the screw holding the sensor to the plate.




- 4 Rotate the device, arms and plate assembly clockwise and remove from sensor.




- 5 Use the T-20 bit to loosen the grips holding the merchandise.




- 6 Use the philips head bit to loosen the screws on the security arm plate.



- 7 Remove the bracket arms.



- 8 Use the InVue multitool (AF6313) with removal attachment in the removal slot to twist and break the adhesive bond of the plate to the merchandise.



SD0426 Rev6 04/03/17

inVue

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2017 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.