

inVue


LTO4 Display Only Unit

Angled Stand and Sensor

(SLD102-B, SLD102-W)


Stud Mount Kit

(DGD403)




1 Stand Installation:

If bolt mounting, drill a 19mm hole minimum (or 9mm slot minimum) in the fixture. Clean the surface of any debris.



2


Clean the fixture surface with the provided alcohol wipe. Let dry completely.



3


Optional:

Install the optional stud kit (DGD403), by threading the stud into the stand.




4

Remove the clear film from the adhesive on the bottom of the stand.




5

Locate stand over the hole or at the desired location on the fixture. Orient the stand so that the coiled cable is facing away from the customer. Press stand against the surface for at least 10 seconds.



6


If optional stud kit is used, attach plate and nut onto the stud and tighten against the fixture.



1


Sensor Installation:

Clean the back of the merchandise with the provided alcohol wipe. Let it dry completely.



2


Place the sensor on the stand and remove the clear film from the adhesive on the merchandising plate.



3a


Optional:

If using an LSE plate, align the slot in the LSE plate with the plunger and slot on the sensor as shown below. Apply pressure for at least 10 seconds.




3b

Remove the paper backing from the LSE plate.



4


Center the merchandise on the sensor (and LSE plate if used) and apply pressure for at least 10 seconds.



5


Optional:

A Zips! basic loop sensor (ZA3002) can be used with the anchor on the back of the stand. Thread the loop through the anchor, pull through and attach the alarm end to the merchandise. Please see the instructions included with the loop sensor (ZA3002) for more details.




1 Stand Removal:

If stud kit was used, unscrew stud mount from the stand.



2


Use the multitool scaper attachment (DNTX93) to break the adhesive bond between the plate and the fixture surface.



1

Sensor Removal:

Use the InVue multitool (AF6313) with removal attachment in the removal slot to twist and break the adhesive bond of the plate to the merchandise.



SD0452 Rev0 04/07/17

inVue

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2017 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.