





LTO4


Replacement Sensor Sled PSA
(ADH2132)




- 1 Use T-20 bit to remove the screw holding the sensor to the merchandising plate.




- 2 Remove the merchandising plate from the sensor by turning it clockwise and pulling it away from the sensor.




- 3 Remove the old adhesive from the plate.




- 4 Clean the replacement sensor sled with a provided alcohol wipe.



- 5 Remove the clear film from the adhesive.



- 6 Apply the exposed adhesive side to the replacement sensor sled. **Ensure that the plunger slot on the adhesive lines up with the slot on the sled.** Apply pressure evenly for at least 10 seconds.



SD0470 Rev1 05/01/17



www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2017 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.