S2800 Accessory Recoilers

HC15170, HC15180

1 Ensure that the slot in the display surface is at least 15mm wide and has access to the hook and loop fastener piece under the counter.

Speaker Recoiler (HC15170)

Headphone Recoiler (HC15180)

2 **If using speaker recoiler:**
Wipe merchandise with the alcohol wipe provided. **Let dry completely.** Remove adhesive liner from cable clip and attach to merchandise. Feed MicroUSB cable through hole in display surface and plug into the merchandise above the counter.

3 Press the recoiler firmly against underside of display surface to attach hook & loop fastener.

4 Connect recoiler to S2800 power box.

2 **If using headphone recoiler:**
Open the cover on the loop sensor. Feed loop sensor and audio connector through hole.

3 Press the recoiler firmly against underside of display surface to attach hook & loop fastener.

4 Wipe merchandise with alcohol wipe provided. **Let it dry completely**. Remove clear film from adhesive.

5 Press sensor firmly onto merchandise for at least 10 seconds. Wrap loop around merchandise. Tightly pull loop through sensor and tighten with T-20 bit.

6 Close door on sensor.

7 Pull zip tie through hole in sensor and wrap it firmly around the headphones. Remove excess zip tie. Plug audio connector into headphones.

8 Connect MicroUSB on recoiler to S2800 power box or aux box.

To play audio:

Thread the audio source connector through the slot and plug it in to an audio source.

SD0354 Rev1 10/14/16

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE
EMEA // +31.23.8900150
APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.