Series 2800

Handheld & Tablet Stand

DNDS11, DNDS22

Read entire instruction guide and confirm below counter installation is complete before starting installation.

System Components

1. Stand
2. Alarm Unit & IR Dot *(sold separately)*
3. Power Box and/or Alarming Only Box *(sold separately)*
4. Sensor *(sold separately)*
5. IR Key *(not included)*

Tools Needed

1. Drill

System Overview

Series 2800 provides power-up, security and magnetic docking. When both power and security are present, the gold light on the sensor will turn on.

Angled Stand
DNDS22W
DNDS22B

Flat Stand
DNDS11W
DNDS11B

InVue IR Key
AF4400 or PK4400

1 ***Optional:*** *Drill a 0.75” (19 mm) diameter hole for stand in display counter. Wipe display counter with alcohol wipe provided.* ***Let it dry completely.***

2a ***Adhesive Mount:*** *Remove clear film from both adhesives. Press stand firmly onto display counter for at least 10 seconds.*

OR

2b ***Screw Mount (optional):*** *Tighten threaded post onto stand. Remove clear film from both adhesives. Slide stand cord and threaded post through fixture. Tighten washer and wing nut onto threaded post.*

3 ***Below Counter:*** *Plug stand cord into power box.*

4 *Place sensor into stand and plug sensor cord into stand.*

SD0247 Rev0 09/08/14

tough security made easy

www.invuesecurity.com

NA / LATAM OFFICE // 704.752.6513 • 888.55.INVUE
EMEA OFFICE // +31.23.8900150
APAC OFFICE // +852.3127.6811

© 2014 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.