



WS1

Stand (AC110/DNWS31W)


Apple Watch Cradle (AC184)




- 1 Route USB end of OEM charger through cradle.




- 2 Determine which adhesive provided is appropriate for OEM charger. Remove film from one side of adhesive.




- 3 Attach adhesive to underside of charger. Press firmly for 10 seconds.




- 4 Remove film from second side of adhesive.




- 5 Press bottom of charger to inside of cradle for 10 seconds.



- 6 Insert stand into cradle.




- 7 Route charger cable along side of side and into bottom of stand.




8

Remove clear film from adhesive on stand cable cover. Insert into cradle, placing on top of charger cable.



9

Screw to stand using a T-20 bit. Press stand cable cover to stand firmly for 10 seconds.




10

Wipe fixture with alcohol wipe provided. **Let it dry completely.**




11

Remove clear film from adhesive on bottom of stand.




12

Route OEM charger cable through hole in fixture. Press firmly onto fixture for 10 seconds.




13

Place Apple Watch with sensor (AC183) onto cradle. Plug sensor into back of stand.



14

Plug OEM charger into OEM power supply. Final assembly should resemble image below.



SD0302 Rev0 09/17/15

inVue

www.invuesecurity.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2015 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.