




## CT311 CT100 Adhesive Mount




**1** Remove tab to activate battery.




**2** Slide stand cable through adhesive plate with adhesive side facing down.




**3** Confirm adhesive plate sits flush against bottom of stand. Fully tighten screw.




**4** Wipe fixture with alcohol wipe provided. **Let it dry completely.**



**5** Remove clear film from adhesive.



**6** Slide cable through fixture or out through adhesive plate. Press firmly for 10 seconds.



SD0267 Rev0 02/04/15