


inVue®

Series 950

Alarm Unit & Camera Sensor
EC95005 & EC95210



Read entire instruction guide before starting installation.

System Components

1. Camera Alarm Unit – EC95005
2. Camera Sensor – EC95210
3. IR Key *(not included)*

Optional for DSLR Camera Only


1. Lens Sensor – EC95211
2. Lens Stand – ZA2500

Tools Needed

1. InVue Multi Tool – AF6313
2. InVue T-20 Bit *(included in multi tool)*


System Overview

The Series 950 Camera provides alarming security and power-up display for all cameras.



Camera Alarm Unit
EC95005

Camera Sensor
EC95210




Power Connector
(determined by merchandise)



InVue IR Key
AF4400 or PK4400



Lens Stand
ZA2500





Lens Sensor
EC95211

Attaching Alarm Unit



Alarm Unit: 2 Parts

- 1) Stand
- 2) Alarm Unit




1

Remove white tab to activate battery. Wipe display counter with alcohol wipe provided. **Let it dry completely.**




2

Remove film from all adhesives on bottom of alarm unit. Confirm plunger is completely depressed on flat surface.



**3**

Press firmly to attach (1) stand onto display counter. Confirm LED window is towards front of display counter. Press firmly to attach (2) alarm unit onto display counter. Note: You can display alarm unit unattached or attached.




Plug power supply into power cord and into outlet.

Attaching Merchandise




1

Loosen screws on sensor with T-20 bit. Pull sensor apart.




2

Attach camera to sensor. Center and tighten screw with T-20 bit. Confirm plunger is completely depressed.




3

Plug power connector into sensor port closest to camera power plug. Note: There are 2 ports power connector can be plugged into.




4

For DSLR only: Plug lens sensor into camera port (opposite power connector).




5

Choose correct size (3 sizes) anti-rotation bracket and place into groove in sensor. Slide sensor together to confirm bracket is up against back of camera. Tighten both screws with T-20 bit.




6a

For DSLR only: Wipe lens with alcohol wipe provided. Let it dry completely. Plug lens sensor into camera sensor. Remove clear film from lens sensor, press firmly onto camera lens and tighten onto lens with zip tie. Place lens sensor towards top of lens.




6b


Optional For DSLR only: Remove clear film from adhesive. Place lens stand below camera to support lens and press firmly for at least 10 seconds. Twist top to adjust height of stand.

**7**

Place sensor into stand. Plug sensor into alarm unit.



Arm or Disarm System



*Place IR key onto IR
lens on alarm unit.
Press button once to
arm or disarm system.*



tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE

Europe, Middle East & Africa // +31.23.8900150

Asia Pacific // +852.3127.6811

Latin America // +52.55.9000.3957