



inVUE®


CT150 Wall Mount and Handle CTBL002, CTBH001




- 1** Route the power cable either through the fixture or along the wall depending on your fixture type.




- 2a** **Drywall Mount Option:**
Drill 2 holes 75mm (3 inches) apart and attach the unit to the wall using hardware appropriate for the position (not provided).




- 2b** **VESA Mount Option:**
Attach a VESA bracket (not supplied by InVue) to the back of the CT150 wall mount unit.




- 3** Place the cover onto the mounted unit. Make sure the the tabs align correctly.




- 4** Attach the 2 parts together using the integrated screws.




- 5** Plug the power cable into the power supply. Plug the the power supply into wall.




- 6** **Handle Attachment to Tablet:**
Using the provided alcohol wipe, clean the back of the tablet. Let it dry completely.



- 7** Remove the small rubber pad from the bag that is included with the kit. Pull the larger rubber bumper out of the handle and insert the small pad into the depression.




- 8** Orient the handle so that the arrow on the top will face the top of the tablet.




- 9** Plug the power connector into the top of the handle.


The power connector should orient towards the bottom of the tablet.




- 10a Optional:**
If using a device with an alternate material backing, LSE plates will be needed. Peel the paper backing from 2 LSE plates.




- 10b** Center the 2 LSE plates, adhesive side down, onto the back of the device. Apply pressure for at least 10 seconds.




- 11** Plug the power connector into the tablet.




- 12** Remove the clear film from the adhesives on the handle.




- 13** Center the top of the handle onto the back of the tablet and apply pressure for at least 10 seconds.




- 14a Optional:**
To attach the connector cover, peel the clear film from the 2 adhesives.




- 14b** Place the cover on the back of the tablet over the power connector. Apply pressure for at least 10 seconds.




- 15a Optional:**
Remove the clear film from the 2 adhesives on the bottom of the cable manager.




- 15b** Route the cable in the gap on the bottom of the cable manager and twist clockwise to remove slack from the cable. Press the cable manager against the tablet for at least 10 seconds.




- 16** Place the handle onto the wall mount unit.




- 17** To remove the handle and tablet from the wall mount, pull the lever on the bottom of the wall mount unit and lift the handle free.



- 18 Optional:** To prevent the removal of the handle, tighten the screw on the bottom of the unit using the TT20 bit in the multitool (AF6313) or TT20 stand alone key fob (AF6330).




- 19** To remove the CT150 handle, use the multitool scaper attachment (DNTX93) to break the adhesive bonds.



20

Use the scraper removal tool to remove the optional covers if used.



SD0528 Rev3 10/31/17

inVue®

Perfectly connecting people and
tablets in the workplace.™

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2017 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.