CT300
iPad Air 2 Frame Button Blockers
CTG2P009

1. Any combination of button blockers may be installed. Note that the home button has to be added after the iPad is installed into frame. All other buttons will be added before iPad is installed.

2. Wipe the areas shown with alcohol wipe provided. Let dry.

3. Remove adhesive from button blockers that are being used.

4. Insert blockers to corresponding holes from inside tablet frame. Press firmly for 10 seconds.

5. Insert tablet into frame.

6. If using home button blocker, remove film from adhesive. Align with notch near home button. Press firmly for 10 seconds.

SD0382 Rev0 07/29/2016

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE
EMEA // +31.23.8900150
APAC // +852.3127.6811

© 2015 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.