CT300
Stand
CTG2E001
CTG2S001

Optional Swivel Lock:

If swivel of stand is not desired, insert dowel as shown. Place adhesive pad provided over hole in bottom of stand to hold dowel in place.

Place adhesive into rectangular slot in bottom of stand.

Bolt Mount:

1A Drill a 25mm (1”) hole in fixture.

2A Wipe display counter with alcohol wipe provided. **Let dry completely.**

3A Thread mounting bolt into the bottom of stand.

4A Route cable as desired, out of the rear of the stand using the center channel or through the hole in counter.

Optional USB Cable (CTG2E001 only)

Plug in USB Extender Cables (CTG2EP001) and then route cables through channels on bottom of stand.

Install optional USB port covers (CTG2EP002).

5A Remove adhesive liners from adhesive dots on bottom of stand.

6A Route power cable and follow with USB cables if applicable through hole in fixture. Insert mounting bolt through hole in fixture.

7A Slide security washer onto mounting bolt. Position cables in opening of plastic washer. Loosely secure with metal wingnut.

8A Press down firmly on stand for 10 seconds. Fully tighten metal wingnut.

Go to step 9.

Adhesive Mount:

1B Wipe display counter with alcohol wipe provided. **Let dry completely.**

2B Clean bottom surface of stand with alcohol wipe provided. **Let dry completely.**

3B Apply adhesive (order code ADH2099) to bottom of stand as shown.

4B Route power cable to central exit. Determine placement location on fixture.

5B If not using USB portsInstall optional USB port covers (CTG2EP002).

6B Verify placement of stand. Remove liners from all adhesive pads and place stand on counter. **Note: Once adhesive is placed on counter, unit cannot be repositioned.**

7B Press down firmly on stand for 10 seconds.

Ready for use in 1 hour, adhesive fully cured in 24 hours.

Go to step 9.

9 Plug the power cable from the stand into power supply, and plug the AC power cable into the power source. Stand will “beep” to confirm it is receiving power.

10 **If using IR key system**, follow instructions that came with key system to assign secure code.

If using InVue CT300 Undock Application, download it from the Windows Store, Apple Store, or Google Play Store now. Follow in app instructions for setup.

If using InVue’s software development kit, follow your IT department’s guidelines for setup.

Docking Frame to Stand:

Note: See frame instructions for frame assembly. Once frame set up complete, use guides to align frame to center of stand dock. Slide tablet into stand receptacle.

An audible tone and LED “ON” indicate that the tablet is securely docked and charging.

Landscape to Portrait Rotation:

Press button to rotate screen from landscape to portrait. **IMPORTANT: Frame MUST be installed/removed in landscape orientation.**

Removing Frame from Stand:

1 Touch InVue IR key* to IR window and press key button or use software authentication. Confirmation “beep” indicates tablet is ready for removal.

*Note: Compatible with all InVue IR keys.

2 Push tablet down slightly, then pull out to remove frame from stand.
Note: Stand will automatically re-lock after 6 seconds if tablet is not removed.

Adhesive Mount Removal (CTG2P002):

1 Position adhesive removal tool so that it wraps around cable exit.

2 Pull handle in a clockwise direction until the adhesive loosens.

SD0371 Rev0 05/15/16

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE
EMEA // +31.23.8900150
APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.