Series 2800

Handheld & Tablet Installation

Read entire instruction guide and confirm below counter installation is complete before starting installation.

System Components

1. Stand
2. Alarm Unit & IR Dot
3. Power Box and/or Alarming Only Box
4. Sensor
5. IR Key *(not included)*

Tools Needed

1. Drill

System Overview

Series 2800 provides power-up, security, magnetic docking and NFC demonstration when lifted by the consumer. When both power and security are present, the gold or blue light on the sensor will turn on.

Stand
DNDS00W
DNDS00B

Sensor

InVue IR Key
AF4400 or PK4400

1 ***Optional:*** *Drill a 0.75” (19 mm) diameter hole for stand in display counter. Wipe display counter with alcohol wipe provided.* ***Let it dry completely.***

2 *Remove clear film from all 4 adhesives, slide cord through display counter. Press stand firmly onto display counter for at least 10 seconds.*

3 ***Below Counter:*** *Plug stand cord into power box.*

Attaching Merchandise

1 *Wipe back of merchandise with alcohol wipe provided.*
Let it dry completely.

2 *Plug power connector into merchandise.*

3 *Remove film from sensor and press firmly onto back of merchandise for at least 10 seconds.*

4 *Place sensor into stand and plug sensor cord into stand.*

Disarm System

1 *Place key on IR dot. Press button on key once to disarm system.*

SD0219 Rev0 04/09/14

tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE
Europe, Middle East & Africa // +31.23.8900150
Asia Pacific // +852.3127.6811
Latin America // +52.55.90003957

© 2014 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.