Series 2800

Camera Sensor

DNCR00

Read entire instruction guide and confirm below counter installation is complete before starting installation.

System Components
1. Camera Sensor
2. Camera Stand
3. IR Key *(not included)*

Tools Needed
1. InVue Multi Tool – AF6313
2. InVue T-20 Bit *(included in multi tool)*

System Overview
The Series 2800 Camera Sensor is designed to provide power-up and security to all cameras. When both power and security are present, the gold or blue light on the front of the camera sensor will turn on.

Camera Sensor
DNCR00

Camera Stand
DNCR11

InVue IR Key
AF4400 or PK4400

Attaching Stand

1 *Drill 19 mm hole in display counter. Wipe counter with alcohol wipe provided.* ***Let it dry completely.***

2a *Remove clear film from stand. Press stand firmly onto display counter for at least 10 seconds.*

2b ***Optional:*** *Drill 19 mm hole. Remove clear film from stand. Slide cord through display counter and press stand firmly for at least 10 seconds.*

3 ***Below Counter:*** *Plug stand into power box.*

Attaching Merchandise

1 *Determine power connector being used: external power connector or battery coupler power connector.*

External Power Connector

Battery Coupler Power Connector

2a ***If using <u>external</u> power connector:*** *Pull back rubber pad and plug power connector and anti-rotation bracket into sensor.*

2b ***If using battery coupler power connector:***
Insert battery coupler into battery compartment and close. Pull back rubber pad and plug power connector and anti-rotation bracket into sensor.

3 *Confirm correct size anti-rotation bracket is in sensor and bracket is against back of camera.*

Note: There are 3 anti-rotation bracket sizes to choose from and 2 positions to place brackets on sensor.

4 *Center camera onto sensor. Tighten screw with T-20 bit.*

5 *Plug power connector into camera.*

6 *Plug sensor cord into stand and place sensor onto stand.*

Disarm System

1 *Place key on IR dot. Press button on key once to disarm system.*

SD0222 Rev0 04/03/14

tough security made easy

www.invuesecurity.com

Corporate Office (North America) // 704.752.6513 • 888.55.INVUE
Europe, Middle East & Africa // +31.23.8900150
Asia Pacific // +852.3127.6811
Latin America // +52.55.9000.3957

© 2014 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.