S2800 Low Profile Camera Sensor with Power
DNCR34

1. Route wire loop through camera eyelet that is **closest** to the battery compartment.

2. Route entire sensor through wire loop.

3. Pull sensor through wire loop. Fully tighten wire loop around camera eyelet.

4. Insert Fob Tool (AF7450) into power compartment. Slide door of power compartment open.

5. Power connector will vary depending on camera model. Plug power connector into power compartment. Slide door of power compartment closed.

6. Plug power connector into camera battery port. Plug sensor into S2800 power box.

SD0331 Rev1 06/10/16

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE
EMEA // +31.23.8900150
APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.